



Model		Arrangement	
	W Full Exposed Wall Mounted	12 Front Bottom In, Top Out	14 Bottom In, Top Out
	WI Full Exposed Inverted Wall Mounted	23 Top In, Front Bottom Out	24 Top In, Bottom Out
(H)	WF Wall/Floor Mounted	32 Front Bottom In, Top Out	
(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	WFI Inverted Wall/Floor Mounted	43 Top In, Front Bottom Out	
	F Floor Mounted w/ Pedestals	52 Front Bottom In, Top Out	54 Bottom In, Top Out
	FI Inverted Floor Mounted w/ Pedestals	63 Top In, Front Bottom Out	64 Top In, Bottom Out